

TURKU 3 Plus

Installation drawings



marking			length	pcs				
	DOOR 92x590x1860 BRONZE			1				
	WOODEN DOOR HANDLE			1				
	WOODEN KNOB FOR DOOR LOCK			1				
	WINDOW 42x1500x500 BRONZE			1				

	18x95 MOULDING EXTRA		~2100	2				
UK-1	18x95 DOOR MOULDING		1890	2				
UK-2	18x95 DOOR MOULDING		790	1				
UK-3	18x60 DOOR MOULDING		560	1				
AK-1	18x95 WINDOW MOULDING		1690	2				
AK-2	18x95 WINDOW MOULDING		1460	2				
AK-3	18x95 WINDOW MOULDING		575	4				

marking			length	pcs				
RN-1	WATER DRAINAGE PROFILE (OPENING RIGHT)			1				
extra	WATER DRAINAGE PROFILE (OPENING LEFT) TO USE AS "MIRROR"			1				
	3 MM DISTANCE DETAIL FOR FLOOR SLOPE		1995	1				
	6 MM DISTANCE DETAIL FOR FLOOR SLOPE		1995	1				
	9 MM DISTANCE DETAIL FOR FLOOR SLOPE		1995	1				
	12 MM DISTANCE DETAIL FOR FLOOR SLOPE		1995	1				


	SPU INSULATION WITH FOIL 30x600x1200			6				
--	--------------------------------------	--	--	---	--	--	--	--



marking			length	pcs				
	SCREW 3,0x40 A2 STAINLESS FOR MOULDINGS			100				
	SCREW 4,8x90 A2 STAINLESS FOR WALL CONNECTIONS (CORNERS)			300				
	SCREW 4,8x55 A2 STAINLESS FOR DECKING BOARDS			200				
	SCREW 3,5x50 AW20 FOR FLOOR BOARDS			100				
	SCREW 4,5x70 FOR ROOF EDGE AND BENCH SUPPORTS			100				
	SCREW 5,0x90 FOR FLOOR FRAME AND WALL CONNECTIONS			100				
	SCREW 5,0x120 FOR WALL CONNECTIONS			25				
	SCREW 6,0x180 FOR ROOF RAFTERS AND WALL CONNECTIONS			25				
	NAIL 75 MM FOR ROOF BOARD			~400				
	NAIL 40 MM FOR CEILING BOARD			~300				
	SCREW 4,8x40 FOR L-IRON			50				
	L-IRON 30x30x130 FOR GRID WALL			3				
	WASHER M5 FOR L-IRON 30x30x130 (GRID WALL)			3				
	ADJUSTABLE LEVELLING BOLT 60x60 FOR CORNER POST			1				
LB-1	L-IRON 40x40x40 FOR CEILING BEAM			6				
	VENTILATION LOUVER WOOD D100			2				
	VENTILATION GRID METAL D100			2				
	FOIL TAPE			1				

40x146 wall logs

		extra	1 pcs	
		01	2 pcs	
		02	2 pcs	
		03	40 pcs	
		03A	2 pcs	
		03C	2 pcs	
		04C	2 pcs	
		05	28 pcs	
		06C	2 pcs	
		07	8 pcs	


TURKU 3 PLUS







FLOOR FRAME 45x95


ADD DISTANCE BOARDS UNDER THE FLOOR BOARDS
FOR FLOOR SLOPE




AR-3 CROSS-SECTION




FLOOR FRAME





FLOOR BOARDS AND DECKING BOARDS




BEFORE THE FLOOR BOARD, INSTALL FLOOR SLOPE DETAILS



FIRST ROW



Use rubber hammer and hammer block




*Fix the first wall row with the screws
90 mm (half row) and 180 mm*

5


**IN EACH CONNECTION USE 90 MM STAINLESS SCREWS
(TO PROTECT THE BUILDING FOR WIND)**




WALL 1




WALL 2




WALL B




WALL A






ROOF RAFTER SR-1 (3 pcs)




RAFTER PLAN




WINDOW MOULDINGS 18x95


OUTSIDE AND INSIDE MOULDINGS ARE WITH THE SAME LENGTH
FIX WITH A 40 MM STAINLESS SCREWS




GRID WALL VS-1



CORNER POST NP-1



Adjustable levelling bolt



1. FIRST FIX THE BENCH SUPPORTS TO THE WALL
2. THEN LIFT THE BENCHES ON TOP OF THEM
3. FIX THE BENCHES WITH THE 70 MM SCREWS TO THE WALLS AND SUPPORTS
4. USE VERTICAL SUPPORT TO SUPPORT THE BENCH FROM THE MIDDLE

BENCH SET

